

Manual, Assembly instruction: Brodit 855826

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1. Attaching part (the smallest part) Part 2. ProClip face plate.

1. Press the angled edge of Part 1 into the gap.. Press Part 1 upward and forward so the angled edge hooks behind the control panel.

2. Hold Part 1 in the correct position, press it upward. At the same time, place Part 2 over the holes in Part 1 so the holes match.

3. Hold part 1 in the correct position, press it upward. At the same time, attach Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.