

## Manual, Assembly instruction: Brodit 856234

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.**

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape covers. Hook the grooved edge on the lower part of the mount over the frame surrounding the air vent.
2. Hook the grooved edge on the upper part of the mount under the frame surrounding the air vent.
3. Press forward on the upper part of the mount so the upper edge hooks properly in place.
4. The ProClip mount is in place. This mount can also be attached onto the left air vent. A device installed in this position may block the display.