

Manual, Assembly instruction: Brodit 856258

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place. This mount consists of two parts: A mounting plate and an attaching piece.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover on the attaching piece. Place the attaching piece onto the compartment frame. Place the left corner of the angled edge sideways into the gap in the panel between the center console and the compartment. Continue to press leftward so all of the angled edge sits all the way in the gap.

2. Hook the upper angled edge of the mounting plate over the panel between the center console and the compartment.

3. Position the face plate over the attaching piece so the holes match. Attach the parts together with the enclosed screws.

4. The ProClip mount is in place.