

Manual, Assembly instruction: Brodit 216145

With MultiMoveClip with sliding power block. Fits devices with both standard and Eliminator battery. Designed for stationary rollers max diameter 127mm, core diameter 25mm. With AMPS, VESA 75 holes.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the product.

1. Location of the screws before mounting, LONG screws 16mm, SHORT screws 9mm. Place the mount onto the device so the holes match. Screw the two enclosed LONG screws in place in the holes shown in the picture. Screw the two enclosed SHORT screws in place in the holes shown in the picture.

2. Put the device into place: Hold the device on the right side of the mount. Slide it leftwards onto the mount so it snaps into place. Mount the cable.

3. Remove the device: Press forward on the release lever and slide the device rightwards away from the mount.

4. The product is in place.